

DISPLAYS / CONTROLLERS	<b>Autohelm</b>
	Everything
	<b>B&amp;G</b>
	Triton <sup>2</sup> digital display
	20/20 HV display for H5000/Triton
	10/10 HV display for H5000/Triton
	Triton <sup>2</sup> autopilot controller
	H5000 graphic display SKU 000-11542-001
	H5000 race display SKU 000-11543-001
	WR10 wireless remote and BT1 base station
	<b>Furuno</b>
	F170 instrument/date organizer
	FAP-7011C + FAP7002 (pack)
	FAP-7001
	<b>Garmin</b>
	Automatic pilote remote control
	GH <sup>TM</sup> 20 automatic helm control
	GMI <sup>TM</sup> 20
	GNX20
	<b>nke</b>
	Multisplay
	TL25
	SL50
	Multigraphic
	Gyrogaphic
	PAD display
	PAD pilot
	Wired display remote control
	Display radio controller
	Pilot remote control
	Crew transmitter
	Gyropilot transmitter
	Display transmitter
Universal radio receiver	
<b>Raymarine</b>	
E70328 p70s colour autopilot control head (sail)	
E70329 p70Rs colour autopilot control head (power)	
A80532 follow-on tiller steer (standby-Power Steer-standby)	
A80602 Autopilot follow-on tiller steer control (Auto-Power steer-Auto)	
E15023 Sea talk Smart Controller remote	
E15024 S100 wireless Sea Talk automatic remote control	
A18104 S100 remote control	
A18105 Smart Controller	
A18106 S100 basis station	
E70063 i40 Speed display system	
E70064 i40 depth display system	

DISPLAYS/CONTROLLERS	<b>Raymarine next</b>
	E70065 i40 Wind
	E70066 i40 Bidata
	E70058 i50 Speed wired instrument (digital display)
	E70059 i50 Depth display (digital display)
	E70060 i50 Tridata (digital display)
	E70061 i60 Wind display (Analog)
	E70062 i60 Close hauled wind display (analog)
	E70327 i70s Multifunction colour display
	T110-868 Wireless mutli digital display
	T111-868 Mutli dual wireless digital display
	T112-868 Wireless mutli analog display
	T113-868 Wireless mutli remote display
	T061 Micro compass with strap bracket (complete with T005)
	T060 Micro compass
	T070-868 Micronet Race Master
	T074-868 Micronet Race Master System and Transducer
	T075-868 Micronet Race Master, Triducer and Solar Panel
	T210 Wireless maxi display "Airflow function inside"
	T215 Wireless Dual Maxi display
<b>Simrad</b>	
IS42 colour instrument display	
IS35 digital gauge	
IS42J Digital gauge	
IS12 display	
WIND	<b>Autohelm</b>
	Everything
	<b>B&amp;G</b>
	213 wind sensor
	WS310 wired wind sensor
	WS320 wireless wind sensor
	<b>Furuno</b>
	CV7 Windyplug
	FI-5001
	FI-5001L
	<b>Garmin</b>
	gWind <sup>TM</sup> Wireless 2
	gWind <sup>TM</sup> transducer
	Wireless gWind transducer
	Wired gWind transducer
<b>LCJ</b>	
CV3F	
CV7 Windyplug	
CV7-C	
CV7-SF2	
CV7-STBG	

APPENDIX H

Production boats' mini rules - Authorized electronic equipment

<b>WIND</b>	<b>LCJ next</b>
	CV7-V
	CV7-HR
	Sonic Anemo DZP
	<b>nke</b>
	Masthead unit HR masthead unit
<b>Raymarine</b>	
T120 Wireless wind system	
T222 Wireless vertical Wind transducer	
Z1295 Wind Rotavecta (20m cable)	
<b>GPS ANTENNAS</b>	<b>Autohelm</b>
	Everything
	<b>B&amp;G</b>
	ZG100 GPS antenna with compass
	<b>Furuno</b>
	GP330B
	ROGPS6
	<b>Garmin</b>
	GPS 19x HVS (NMEA 0183)
	GPS 19x NMEA 2000®
	GPS 24xd
	GPS GA™ 38GPS / GLONASS antenna
	<b>nke</b>
	External passive GPS antenna
	High frequency GPS
<b>Raymarine</b>	
T908 GPS antenna with NMEA 0183	
<b>Simrad</b>	
GS25 GPS antenna	
<b>COMPUTERS</b>	<b>B&amp;G</b>
	NAC-2 autopilot computer
	NAC-3 autopilot computer
	H5000 computer sealed with Hydra version
	H5000 pilot controller sealed with hydra version. SKU 000-11544-001
	H5000 pilot computer sealed with Hydra version SKU 000-11554-001
	<b>Furuno</b>
	FAP-3012
	FAP-7002
	<b>Garmin</b>
	CCU (Course Computer Unit) Reactor 40
	ECU (Unité de Contrôle Electronique)
<b>nke</b>	
Gyropilot 2 computer	
Gyropilot 3 computer	

<b>COMPUTERS</b>	<b>Raymarine</b>
	E70097 EV2 Evolution Sensor core
	E70098 ACU-100 Acuator control unit
	E70099 ACU-200 Acuator control unit
	E70100 ACU-400 Acuator control unit
	E70139 ACU-300 Acuator control unit
E70430 ACU-150 Acuator control unit	
<b>COMPASSES</b>	<b>Autohelm</b>
	Everything
	<b>B&amp;G</b>
	Precision-9 compass
	<b>Furuno</b>
	PG500
	PG700
	<b>Garmin</b>
	9-axis heading sensor
	SteadyCast™ heading sensor
	Marine Heading Sensor
	<b>Lars Thrane</b>
	LT500
	LT1000
	<b>nke</b>
	9x compass
	Fluxgate compass
	Regatta compass
Regatta compass bus interface	
<b>Raymarine</b>	
E70096 EV1 evolution sensor core	
T909 Wireless Compass Transducer	
<b>TRANSDUCERS</b>	<b>Autohelm</b>
	Everything
	<b>B&amp;G</b>
	DST810 Depth/Speed/Temperature sensor with plastic housing
	DST800 Depth/Speed/Temperature sensor with plastic housing
	DT800 depth and temperature sensor
	H5000/3000 flush plastic speed sensor
	<b>Furuno</b>
	DST800
	<b>Garmin</b>
	Airmar DST810 thru-hull smart transducer
	GTEMP10-TH thru-hull temperature sensor
Water speed sensor (4 pins)	
<b>nke*</b>	
Paddle wheel speed sensor	
Depth sounder	

APPENDIX H

Production boats' mini rules - Authorized electronic equipment

<b>TRANSDUCERS</b>	<b>Raymarine</b>
	A22112 DT800 Smart Plastic Depth, Temp. Transducer 12° Tilted Element
	A22165 Plastic Smart Transducer Th 0deg tilt DT800
	A22111 i70s active depth/speed and temperature sensor
	A80373 P79S Smart Depth In Hull Depth Transducer with Fitting Kit, NMEA2000
	T720278 Smart Depth in-Hull Depth Transducer (DeviceNet Connector + STng adapter)
	E26009 Thru-Hull depth plastic transducer (9m cable)
	M78713-PZ P19 LP TH Thru-Hull depth plastic (14m cable)
	E26030 Thru-hull Depth transducer retractable (13,8m cable)
	E26027-PZ Transom mount Depth Transducer (13m cable)
	E26001-PZ P79 In Hull Depth Transducer
	E26010-PZ bronze TH Long Stern Depth Transducer (13,8m cable)
	E26006-PZ Transom mount Depth/Speed/temp (9m cable)
	A22154 DST800 analog triducer
	E26028-PZ Transom mount Triducer (9m cable)
	A26043 Thru-hull bronze triducer (13,8m cable)
	A26044 B744VL Long stern bronze thru-hull triducer (13,8m cable)
	E26005 Speed temperature Transom mount transducer (13,8m cable)
	E26031 Thru-hull speed/temperature plastic transducer (13,8m cable)
	E25025 Plastic Thru-hull speed/temperature sensor (20m cable)
	M78716 Bronze thru-hull speed/temperature sensor (13,8m cable)
	T910 Triducer sensor (Speed, depth and Temp.)
	T911 Speed/temperature sensor
	T905 Depth transducer (50mm thru/in hull)
	T912 Thru-hull retractable Transducer
	<b>Simrad</b>
	IS12 Speed and Depth transducer

\*Grandfather clause  
 nke electromagnetic speed sensor (airmar) for boats equipped with before January 1, 2022

<b>TILLERS</b>	<b>Autohelm</b>
	Everything
	<b>Raymarine</b>
	A12004 ST1000 Plus
	AT12005 ST2000 Plus
	<b>Simrad</b>
	Tillerpilot 22, SimNet/NMEA
	Tillerpilot 32, SimNet/NMEA
	Tillerpilot TP10
	<b>Autohelm</b>
Everything	
<b>B&amp;G</b>	
RF25 Rotary rudder feedback sensor	
RF300 Rotary rudder feedback sensor	
H5000 Barometric Pressure sensor	
<b>Furuno</b>	
FI-5002	
IF-NMEA FI	
<b>Garmin</b>	
GN10™ NMEA 2000® transceiver	
GND10	
<b>LCJ</b>	
Baroplug NMEA2000	
<b>nke</b>	
Analog monitor interface	
Log/sounder interface	
Dual Log&sounder interface	
HR100 Barometer	
Battery monitor	
True wind option	
12/13,6V converter	
Bus alimentation filter	
Rudder angle sensor	
12V clutch option	
Input option	
NMEA input interface	
<u>Minimum</u> Class B AIS transpondeur	
<b>Raymarine</b>	
E70010 Multiple POD converter for ITC5 transducer	
E70361 Micronet to SeaTalkNG Gateway (WirelessWind)	
M81105 Rudder angle transducer (10m cable)	
T121 Wireless Hull Transmitter	
T122 Wireless NMEA Interface	
T138 Solar Panel for Hull Transmitter	

Reminder : Thu-hulls can only be used for log/speedos/depts sounders, their standard plugs and the pins